# 13. How to disassemble of refrigerator compartment

1. Remove the chilled compartment cover and its shelf.
   - Lift up the cover, push the cover (as shown) until the mounting hook (①)disengaged, then disengage the other mounting hook (②)and pull out the cover.
   - Pull the shelf forward until it stops, then lift it up and it out.




2. Remove the shelves from the fresh food comparment.
   - First remove food from the comparment. With shelf front raised slightly, pull it forward to disengage.



3. Disengage the hooks on the lamp cover of the damper cover.



4. Replace the bulb.
   (Before replacing check the voltage and current of the bulb. Use rated bilbs only.)